

# LRI 304<sup>TH</sup> ST LANDFILL ASBESTOS WASTE ACCEPTANCE PROCEDURES

The following disposal conditions are based on Puget Sound Clean air Agency (PSCAA) and Department of Safety and Health (DOSH) regulations:

All demolition waste, mobile homes or other building must have proper documentation for disposal at the landfill .

## **FOR ALL ASBESTOS CONTAINING MATERIALS (ACM)**

All documentations must be received 24 hours prior to delivery of ACM at our facility. You can fax documents to 253-875-7205 or email to OlivierA@wasteconnections.com

Asbestos delivery will be accepted between the hours of 9:00 and 15:00 on Tuesdays and Thursdays , unless prior arrangement have been made.

No asbestos waste can be unloaded using the landfill tipper .All asbestos waste must be delivered to the landfill in vehicles and containers that do not require unloading by landfill tipper.

All ACM will be disposed in a designated area ,this area will not be compacted until cover as been applied to prevent damage to ACM and release of fiber.

## **REQUIRED DOCUMENTATIONS:**

### **1.FOR PROJECT WHERE NO ASBESTOS WAS FOUND ( Demolition waste,Mobile homes and other structures ):**

A copy of the Asbestos Survey or a letter from a certified AHERA building inspector that no asbestos was found during inspection of building must be provided to the landfill prior to arrival for disposal.

### **2. FOR A PROJECT WHERE ASBESTOS WAS FOUND:**

A letter of completion from a AHERA certified contractor stating that all asbestos was removed from the building. This applies to disposal of all demolition waste and structural components of buildings .

A copy of the letter of intent or electronic filling (available at PSCAA website)

A waste shipment record ( a copy of waste shipment record can be provided by LRI upon request )

#### **2.1 Packaging requirements:**

All ACM shall be wetted down and packaged in such a manner that it does not become airborne during unloading at the facility (double bagged or containerized) .

To minimize the potential for damage to the packaging , **asbestos will be unloaded from trucks either by the use of a forklift , by using an excavator and sling for large object or hand unloaded by customer for small bags ,dumping from dump truck is not acceptable .**

**In the event that packaging was to become damaged during unloading .LRI would wet down the ACM and cover immediately with a foot of soil or other appropriate daily cover to prevent release of asbestos fiber.**

**Additional information can be obtained by contacting the following agencies:**

Puget Sound Clean Air Agency 206-689-4058 or [asbestos@pscleanair.org](mailto:asbestos@pscleanair.org)  
Department of Labor and Industry 360-902-5514

**Resources:**

- Asbestos Hazard and Emergency Response Act (AHERA) Asbestos School Hazard Abatement and Reauthorization Act (ASHARA) 40 CFR 763 US EPA
- Asbestos Tremolite,Anthophyllite and Actinolite WAC296 62-077 /07761(Part I-1)
- Asbestos Removal and Encapsulation,WAC296 65-001 /050
- WISHA regional directives 23.10, 23.35 ,23.25
- Asbestos Control standards and Forms,Regulation III,Article 4 (PSCAA)